

Virtual Machine Configuration

General


Name: Windows 7

CPUs: 1 (of 4)

Memory: 2.5 GB (of 8)

Options

Startup and Shutdown



The screenshot shows the 'Windows 7 - Options' dialog box with the 'Startup and Shutdown' tab selected. The interface includes a search bar, a navigation pane on the left, and a main content area with settings. A yellow warning box at the top right states: 'Some of the settings on this page cannot be changed until the virtual machine is shut down.' The settings are as follows:

Setting	Value
Start Automatically:	Never
Startup View:	Same as last time
On VM Shutdown:	Keep window open
On Window Close:	Ask me what to do
Undo Disks:	Disable

At the bottom left, there is a lock icon and the text 'Click the lock to prevent further changes.' At the bottom right, there is a help icon (a question mark in a circle).

Optimization

Windows 7 - Options

General Options Hardware Security

Search

Startup and Shutdown

Optimization

Sharing

Applications

Coherence

Full Screen

Modality

Advanced

Some of the settings on this page cannot be changed until the virtual machine is shut down.

Performance: Faster virtual machine

- Enable Adaptive Hypervisor
- Tune Windows for speed

Power: Better performance

- Show battery in Windows

Free Space: Automatically compress virtual disks

- Enable PMU virtualization

Click the lock to prevent further changes.

?

Applications

Windows 7 - Options

General Options Hardware Security

Search

Startup and Shutdown

Optimization

Sharing

Applications

Coherence

Full Screen

Modality

Advanced

- Share Windows applications with Mac
 - Show Windows applications folder in Dock
 - Show Dock icons in Coherence only
 - Pause Windows when no applications are open
 - Dock icons bounce to alert
- Share Mac applications with Windows

Web Pages: Open in Mac


Email: Open in Mac

More Applications...


Click the lock to prevent further changes.

?


Coherence




Full Screen



Modality




Advanced




Hardware


Boot Order




Video



Mouse and Keyboard



Print



Floppy Disk

Windows 7 - Hardware

General Options Hardware Security

Search

- Boot Order
- Video
- Mouse & Keyboard
- Print
- Floppy Disk**
- CD/DVD 1
- Hard Disk 1
- Network 1
- Sound
- USB & Bluetooth

Connected

Source:

Click the lock to prevent further changes. ?

CD/DVD 1

Windows 7 - Hardware

General Options Hardware Security

Search

- Boot Order
- Video
- Mouse & Keyboard
- Print
- Floppy Disk
- CD/DVD 1**
- Hard Disk 1
- Network 1
- Sound
- USB & Bluetooth

Some of the settings on this page cannot be changed until the virtual machine is shut down.

Connected

Connect to:

Location:

Click the lock to prevent further changes. ?

Hard Disk 1

Windows 7 - Hardware

General Options Hardware Security

Search

Some of the settings on this page cannot be changed until the virtual machine is shut down.

Connected

Source:

Expanding disk, 64.0 GB

Location:

Click the lock to prevent further changes. ?

The screenshot shows the 'Hardware' tab in the Windows 7 VM settings. The left sidebar lists various hardware components, with 'Hard Disk 1' selected. The main area displays the configuration for this hard disk, including a 'Connected' checkbox, a 'Source' dropdown menu set to 'Windows 7-0.hdd', a note that it is an 'Expanding disk, 64.0 GB', and a 'Location' dropdown menu set to 'SATA 0:1'. There are also buttons for 'Edit...' and 'Compress...'. A yellow warning box at the top states that some settings cannot be changed until the VM is shut down. At the bottom, there is a lock icon and a question mark icon.

Network 1

Windows 7 - Hardware

General Options Hardware Security

Search

Some of the settings on this page cannot be changed until the virtual machine is shut down.

Connected

NIC Type:


Type:

MAC address:


Click the lock to prevent further changes. ?

The screenshot shows the 'Hardware' tab in the Windows 7 VM settings. The left sidebar lists various hardware components, with 'Network 1' selected. The main area displays the configuration for this network adapter, including a 'Connected' checkbox, a 'NIC Type' dropdown menu set to 'Intel(R) PRO/1000 MT', a 'Type' dropdown menu set to 'Default Adapter', and a 'MAC address' field set to '00:1C:42:91:33:99' with a 'Generate' button. A yellow warning box at the top states that some settings cannot be changed until the VM is shut down. At the bottom, there is a lock icon and a question mark icon.

Sound



USB and Bluetooth



Security



Drive Mapping

Open up My Computer / Windows Explorer / Windows button + E
Click on the "Computer" icon in the left Column
Select "Map Network Drive" from the toolbar menu

Below is the screenshot of my setup:

